

GSM Interface Module

Installing and Wiring Details

If your home security system was installed or is being maintained by a security company, please consult them first before installing the GSM interface module.

The GSM Interface module is fitted inside the main security control panel. Mount the board in a suitable position but away from any mains cables or drop down mains transformer.

Position the board with the GSM antenna facing upwards or outwards, where you believe it is more likely to pick up the best mobile signal.

The wiring cable harness supplied with the module has three wires inserted into a connector, which mates to the connector on the printed circuit board unit: RED, BLACK and BLUE.

See the diagram below for the correct connection details.

RED:	+12 Volt Positive battery or power source	Positive Power
BLACK:	0 Volt Negative battery or power source	Negative Power
BLUE:	-ve trigger of the alarm system on the main board	Input Wire -ve switch

Please observe polarity. Do Not connect any of the wires to any other part of the alarm system. If you are unsure of the wiring details please consult a qualified alarm installer.

